
VERTICAL AB BENCH

Model #: 675VC



Caution: Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.

Assembly Instructions

Contents

Contents	1
Before You Begin	2
Assembly Steps	} -5
Parts & Hardware List	. 6

Assembly Instructions

Before Your Begin

This exercise equipment is built for optimum safety. Be sure to read the entire manual before you assemble or operate your equipment. Please note the following safety precautions:

- 1. Keep children and pets away from the equipment at all times. Do not leave children unattended in the same room with the equipment.
- 2. Only one person at a time should use the equipment.
- 3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms STOP the workout at once.
 - CONSULT A PHYSICIAN IMMEDIATELY.
- 4. Position the equipment on a clear, level surface. DO NOT use the bench near water or outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the equipment.
- 7. Use the equipment only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- 8. Before using the equipment, always do stretching exercises to properly warm up.
- 9. Never operate the equipment if the equipment is not functioning properly.

Tools Required

Tools Required : Allen Wrentch Set / Socket Wrentch Set Adjustable Wrentch / Crescent Wrench Rubber Mallet / Tape Measure

ASSEMBLY REQUIRES AT LEAST THREE PERSONS

WARNING: This Product Is Rated for Home Use Olnyl


Using this product in a commercial setting will void all warranties and can result in serious injury or death!

Note: Hand tighten bolts and nuts until machine is fully assembled.


Page 2

Assembly Instructions STEP 1 $3x_2$ (13) $(14)_{X2}$ (H10-16)x6 (H10-2)_{x2} (0) 1 10 15_{x2} 18x(N10) 32x(W10) Page 3

Assembly Instructions STEP 2



Assembly Instructions STEP 3



Assembly Instructions

Parts & Hardware List

Part#	Description	Qty	Remark
1	Right Front Upright Frame	1	
2	Left Front Upright Frame	1	
3	50x70 Inner Cap	2	Pre-assembled
4	Right Bottom Frame	1	
5	Left Bottom Frame	1	
6	50x70mm Outer Cap	4	
7	Right back Upright Frame	1	
8	Left back Upright Frame	1	
9	Bottom Cross Frame	2	
10	Lower Cross Frame	1	
11	Up Cross Frame	1	
12	Long pipe	1	
13	Short pipe	1	
14	Roller Pad	2	
15	Triangle Bracket	2	
16	Back Pad Mount	1	
17	50x25 Inner Cap	4	Pre-assembled
18	Long Axis	1	
19	Sliding Block	1	
20	Short Axis	1	
21	Lock Pin	1	
22	Incline Adjustment Bar	1	
23	Back Pad	1	
H8-11	Hex Head BoltM8x65	4	
H10-2	Hex Head Bolt M10x20	6	
H10-16	Hex Head Bolt M10x90	6	
H10-17	Hex Head Bolt M10x95	14	
H12-26	Hex Head Bolt M12x150	1	
W8	M8 Washer	4	
BW10	Big M10 Washer	8	
W10	M10 Washer	36	
N10	M10 Nut	18	
W12	M12 Washer	2	
N12	M12 Nut	1	

Limited Warranty

We warrants this product to be free from defects in workmanship and materials under normal use and conditions for a period of 1 year FROM THE DATE OF ORIGINAL PURCHASE. This Limited Warranty is not transferable and is available only for the original purchaser of the product. The company's obligation under this warranty is limited to replacing or repairing the product, at the discretion of the company.

This Limited Warranty is void if the product is:

Damaged through improper use, negligence, abuse, misuse, transportation damage, act of nature, or accident, include failure to follow the assembly and or operation instructions supplied with the product.

Used in commercial or rental applications.

Modified or repaired by anyone not authorized by the company.

This Limited Warranty does not cover expendable items including but not limited to: Batteries, light bulbs, fuses, accessories, and other items that experience wear as a result of normal use.